#### Fit Flexibly !

Offering ultrasonic inspection on various shapes (curved/uneven/gap/rough surface).

#### Cartridge Type Available !

Easy to change element size and set frequency as this transducer is cartridge type.


### High S/N Ratio and Narrow Dead Zone !

With improved S/N ratio during transmission and reception of ultrasonic waves, you can detect a defect that exists directly under the surface because dead zone of this transducer is narrow.



Butt welding part





Defect Inspection 1mm away under the curved surface

Narrow groove part



Gas-cut surface of the reinforcing bar







Convex surface



You can choose type and frequency as the cartridge type

# Ultrasonic Soft Transducer









Improved S/N ratio by the transducers' own structure. It not only allow you to inspect welding zone, casting and aluminum diecasting but is also useful to detect defects near the surface owing to narrow dead zone. It can be used in the field of metal, civil engineering, construction, plant, road, bridge, electronics, medical, etc.

Cartridge type

Case type

Flat type

Pencil type


Ultrasonic Sensor JAPAN PROBE

## Soft Fitting ! Ultrasonic Soft Transducer ! JUTAN

The soft transducer 'JUTAN' is made of soft materials, and provide 'high S/N ratio' and 'narrow dead zone'. It allows to create narrow dead zone, by improving S/N ratio during transmission and reception of ultrasonic waves. As the result, we can inspect and measure a defect near the surface, or welding zone, casting, aluminum diecasting, high damping materials.

- Application
- Metal
   Civil engineering, Construction
- Automobile
   Aerospace
   Machinery
- Chemical, petrochemical plant
  Electronics
- Road, BridgeMedical field, etc.

- Target
  - Metal Resin Human Body, etc.
  - Specifications (Customizable)
    - Frequency : 1~10MHz
       Element Size : Φ3~20mm
       Type : Single / Dual element straight beam
  - Туре
  - Cartridge type / Case type / Flat type / Pencil type
  - Usage



Butt welding part



Fillet welding part





Rough surface of the casting



Gap area



Narrow space area



Concave surface



Convex surface

We accept your <u>samples for test</u>, free of charge, and devices are available to rent !

Search <u>"Japan Probe"</u> and visit website for solution videos.



% We offer customized products based on customers' needs. Please visit 'contact us' by WEB site below.

JP building, 1-1-14, Nakamura-cho, Minami-ku, Yokohama, Kanagawa, 232-0033 JAPAN TEL : +81-45-242-0531 FAX : +81-45-242-0541 URL : http://www.jp-probe.com/en/ E-mail : info@jp-probe.com